

Success beyond the surface.



Installation guide for CowTrax

Thank you for purchasing CowTrax road mat

- 1.** Unpack CowTrax and roll it out across the road with the wired long edge spanning the road.
- 2.** The eyelets at each end of the wire rope are used to pin down the CowTrax. The wire ropes are not to be used to tow the mat.
- 3.** At each short end of the mat there is a sleeve with two cut-out handles in it. This sleeve is for placing a long pipe for added rigidity. We recommend a steel pipe that is between 50-70mm in diameter and as close to the width of the Cowtrax mat as possible in length (not supplied).
- 4.** A short rope can be tied to the pipes inside the handles at one end. This will help you to drag the mat across the road and to fold it up at job's end. You can drag the mat by hand or by using a quad.
- 5.** Your CowTrax should be folded and removed from the road after use.
- 6.** Cleaning of the CowTrax is made easy by attaching the rope to a quad or motor bike, and towing the mat upside down around the nearest clean paddock.

